



Capricorn FLX™ Weather Station User Manual



Capricorn FLX™ Weather Station

User Manual

Version 1.27

Serial Number: _____

Date Purchased: _____

All specifications subject to change without notice.

Printed in U. S. A.

© Copyright 2021 Columbia Weather Systems, Inc. All Rights Reserved.

Proprietary Notice: Capricorn 2000, Capricorn 2000MP, Capricorn 2000EX, Capricorn FLX, Weather Display Console, WeatherMaster and Weather MicroServer are trademarks of Columbia Weather Systems, Inc. The information and drawings contained herein are the sole property of Columbia Weather Systems, Inc. Use of this publication is reserved exclusively for customers of Columbia Weather Systems, Inc. and their personnel. Reproduction of this material is forbidden without the express written consent of Columbia Weather Systems, Inc.

Welcome!

Congratulations on your purchase of the Capricorn FLX Weather Station.

The Capricorn FLX is a precision instrument that requires proper installation and a certain amount of regular maintenance.

Please read this manual completely prior to installation.

Important Notice: Shipping Damage

BEFORE YOU READ ANY FURTHER, please inspect all system components for obvious shipping damage. The Capricorn FLX is a high precision instrument and can be damaged by rough handling. Your unit was packaged to minimize the possibility of damage in transit. Therefore, we recommend that you save the shipping container for any future shipment of your Capricorn unit.

In the event your order arrives in damaged condition, it is important that the following steps be taken immediately. The title transfers automatically to you, the customer, once the material is entrusted to the transport company.

NOTE: DO NOT RETURN THE INSTRUMENT TO COLUMBIA WEATHER SYSTEMS until the following steps are completed. Failure to follow this request will jeopardize your claim.

1. Open the container and inspect the contents. Do not throw away the container or any damaged parts. Try to keep items in the same condition as originally received.
2. Notify the transport company immediately in writing, preferably by facsimile, about the shipping damage.
3. Wait for the transport company's representative to inspect the shipment personally.
4. After inspection, request authorization from Columbia Weather Systems for return of the damaged instrument by calling (503) 629-0887.
5. Return approved items to us at the following address:

Columbia Weather Systems, Inc.

5285 NE Elam Young Parkway, Suite C100

Hillsboro, OR 97124

6. After return authorization is issued and we receive the instrument, an estimate of the cost of repair will be sent to you for submittal to the transport company as a claim.

Table of Contents

WELCOME!	3
IMPORTANT NOTICE: SHIPPING DAMAGE	4
SECTION 1: INTRODUCTION	9
THE CAPRICORN FLX SYSTEM	9
TECHNICAL SPECIFICATIONS	9
<i>Temperature</i>	9
<i>Barometric Pressure</i>	9
<i>Wind Speed (Standard)</i>	10
<i>Wind Direction (Standard)</i>	10
<i>Relative Humidity</i>	10
<i>Rainfall</i>	11
<i>Solar Radiation Sensor (Pyranometer)</i>	11
<i>Power Supply</i>	11
<i>Control Module</i>	11
SECTION 2: PHYSICAL DESCRIPTION	13
CONTROL MODULE	14
STANDARD WIND SENSOR	16
<i>Wind sensor components</i>	17
HEATED WIND SENSOR	18
<i>Wind Sensor components</i>	19
TEMPERATURE SENSOR	24
RELATIVE HUMIDITY SENSOR	25
TIPPING BUCKET RAIN GAUGE (OPTIONAL)	26
<i>Rain Gauge Installation</i>	27
<i>Tipping Bucket Rain Gauge Options</i>	28
<i>Heated Option</i>	28
<i>4 – 20mA Interface Option</i>	28
SOLAR RADIATION SENSOR - PYRANOMETER (OPTIONAL)	29
WEATHERMASTER™ SOFTWARE (OPTIONAL)	30
WEATHER MICROSERVER™ (OPTIONAL)	31
WEATHER DISPLAY CONSOLE (OPTIONAL)	32
SECTION 3: INSTALLATION	33
WIRING AND COLOR CODE	33
INSTALLATION OVERVIEW	35
UNPACKING THE UNIT	35
<i>Installing the Control Module</i>	36
INSTALLING THE MAST	36
ROUTING THE SENSOR CABLES	36

BAROMETRIC PRESSURE SENSOR SETTINGS	37
INSTALLING THE TEMPERATURE AND HUMIDITY SENSORS.....	38
INSTALLING ADDITIONAL TEMPERATURE SENSORS	39
INSTALLING THE STANDARD WIND SENSOR	39
<i>Assembling the Standard Wind Sensor</i>	39
<i>Mounting Method</i>	42
INSTALLING THE HEATED WIND SENSOR.....	42
INSTALLING THE R.M. YOUNG WIND MONITOR	44
INSTALLING THE RAIN GAUGE SENSOR	45
INSTALLING THE SOLAR RADIATION SENSOR	46

SECTION 4: OPTIONAL SENSOR MOUNTING

HARDWARE	47
<i>Sensor Mast</i>	47
<i>Roof Mounting</i>	47
<i>Wall Mounting</i>	49
<i>Telescoping Tripod and Tiedown Kit</i>	50
<i>Tripod Parts List</i> :.....	51
<i>Specifications</i>	51

SECTION 5: OPERATION.....53

CONNECTING THE CONTROL MODULE TO A COMPUTER	53
OPERATING SOFTWARE.....	53
COMMUNICATION SETTINGS.....	53
<i>RS-232 Output</i>	54
CONNECTING THE CONTROL MODULE TO THE WEATHER MICROSERVER	55
CONNECTING THE CONTROL MODULE TO THE WEATHER DISPLAY CONSOLE....	55

SECTION 6: OPTIONAL CONFIGURATIONS.....57

RS-485 CONFIGURATION	57
WIRELESS SYSTEM	59
SOLAR POWERED SYSTEM	61
CAPRICORN FLX 420 SYSTEM.....	62
<i>420 Weatherproof Enclosure</i>	63

SECTION 7: CALIBRATION.....65

CALIBRATING THE BAROMETRIC PRESSURE SENSOR.....	65
<i>Altitude Setting</i>	65
CALIBRATING THE STANDARD WIND SENSOR	65
CALIBRATING THE R.M. YOUNG WIND MONITOR	65
CALIBRATING THE HUMIDITY SENSOR	66
CALIBRATING THE RAIN GAUGE SENSOR	66
CALIBRATING THE SOLAR RADIATION SENSOR	66

SECTION 8: MAINTENANCE.....67

CONSOLE MAINTENANCE	67
BAROMETRIC PRESSURE SENSOR MAINTENANCE.....	67
TEMPERATURE SENSOR MAINTENANCE	67
STANDARD WIND SENSOR MAINTENANCE	67
R.M. YOUNG WIND MONITOR MAINTENANCE.....	67
RELATIVE HUMIDITY SENSOR MAINTENANCE.....	67
RAIN GAUGE MAINTENANCE.....	67
SOLAR RADIATION SENSOR MAINTENANCE	68

SECTION 9: TROUBLESHOOTING.....69

WIND SENSOR (STANDARD)	69
<i>Wind Speed Test</i>	69
<i>Wind Direction Test</i>	69
TEMPERATURE SENSOR TROUBLESHOOTING	71

SECTION 10: USER SUPPORT INFORMATION73

LIMITED WARRANTY.....	73
<i>EXCLUSIONS</i>	73
RETURN FOR REPAIR PROCEDURE	75
FIRMWARE LICENSES AND COPYRIGHT INFORMATION	77

REFERENCE.....88

GLOSSARY	88
<i>Aspirating Radiation Shield</i>	88
<i>Barometric Pressure</i>	88
<i>Celsius Temperature Scale</i>	88
<i>Density Altitude</i>	88
<i>Dew Point</i>	88
<i>Fahrenheit Temperature Scale</i>	88
<i>Global Radiation</i>	88
<i>Heat Index</i>	89
<i>Pyranometer</i>	89
<i>Relative Humidity</i>	89
<i>Sea Level Pressure</i>	89
<i>Solar Radiation</i>	89
<i>Wind Chill</i>	89
UNIT CONVERSION	89
<i>Speed</i>	89
<i>Temperature</i>	90
<i>Distance</i>	90
<i>Pressure</i>	90
<i>Solar Radiation</i>	90

SECTION 1: INTRODUCTION

The Capricorn FLX System

Designed around a Control Module that is housed in a compact, utility-grade enclosure. The Capricorn FLX offers serial communication over RS-232 or RS-485 to various monitoring options.

Features include:

- Modular design for sensor selection and optimal sensor location
- Proven, reliable mechanical wind sensors
- Temperature and/or humidity in self-aspirating radiation shield
- Many other meteorological sensor options
- Two additional general-purpose analog channels
- Low power consumption
- One-year warranty

Technical Specifications

Temperature

Up to four temperature sensors can be connected to the Capricorn FLX.

Type: Digital Semiconductor

Range: -67° to 257°F

Accuracy: $\pm 0.9^{\circ}\text{F}$ from +14° to 185°F ($\pm 0.5^{\circ}\text{C}$ from -10° to 85°C)
 $\pm 3.6^{\circ}\text{F}$ from -67° to 257°F ($\pm 2.0^{\circ}\text{C}$ from -55° to 125°C)

Resolution: 0.01°F

Cable Length: maximum 400 ft.

Barometric Pressure

The board mount precision barometric pressure sensor provides accurate pressure data with full temperature compensation. The sensor outputs are digitized by a high resolution 24-bit analog to digital converter.

Type: Digital Semiconductor

Range: 14.8 to 32.5 inHg (500 to 1100 hPa)

Accuracy: ± 0.03 in. Hg (1 hPa)

Resolution: 0.001 in. Hg (0.03 hPa)

Wind Speed (Standard)

Type: Sealed Reed Switch

Accuracy: ± 0.25 mph from 0 to 23 mph, $\pm 1\%$ from 24 to 160 mph

Range: 0 to 160 mph (139 knots)

Resolution: 1 mph

Starting Threshold: 0.9 mph

Wind Direction (Standard)

Type: Precision Potentiometer

Resolution: 2 degrees

Mechanical Range: 0 to 360 degrees

Electrical Range: 0 to 356 degrees

Accuracy: ± 4 degrees

Relative Humidity

Type: Capacitance

Range: 0 to 100%RH

Accuracy:

From 0 to +40 °C:

0 - 90 %RH: ± 3 %RH

90 - 100 %RH: ± 5 %RH

From -40 to 0 °C and +40 to +60 °C:

0 - 90 %RH ± 5 %RH

90 - 100 %RH ± 7 %RH

Stability: $\pm 2\%$ RH over 2 years

Resolution: 1% RH

Rainfall

Type: Tipping Bucket

Accuracy: $\pm 1\%$ at 2 in/hr or less

Resolution: 0.01 inch

Solar Radiation Sensor (Pyranometer)

Type: High Performance Silicon Photodiode

Cosine Response: $\pm 2\%$ at 45° zenith angle, $\pm 5\%$ at zenith angle 75°

Calibration Uncertainty: $\pm 5\%$

Measurement Repeatability: $< 1\%$

Non-linearity: $< 1\%$ (maximum radiation measurement is 1250 W/m-2)

Field of View: 180°

Sensitivity: Custom calibrated to exactly 5.00 W/m-2 per mV

Operating Environment: -40 to 70°C, 0 to 100% relative humidity

Power Supply

Powered by a wall mount transformer

Input: 120 VAC, 60 HZ, 16 W

Output: 12 VDC, 2.08 A

Control Module

Input Voltage: 12VDC

Operating Temperature Range: -40 to 185°F (-40 to +85°C)

Current Consumption: 10mA @ 12VDC

Dimensions: 5.8" L x 4.5" W x 2.4" H

Weight: 0.4lbs

SECTION 2: PHYSICAL DESCRIPTION



Control Module



The Control Module consists of a System board housed in a light grey 3mm ABS plastic enclosure with a tongue-and-groove cover.

The front panel of the Control Module includes 12 terminal blocks for sensor connections, a serial communication port, a grounding lug and a power input connection.

The System board includes a board mount Barometric Pressure Sensor.

During operation the Yellow LED next to the power input remains solid and the Red LED next to the terminal block, blinks once per second.


The Control Module can also be housed in a weatherproof enclosure along with an internal power supply and an optional wireless transceiver or a MicroServer.

Technical Specifications:


Current Consumption: 10mA @ 12VDC

Dimensions: 5.8" L x 4.5" W x 2.4" H

Weight: 0.4lbs



Front View



Dimensions in Inches

Standard Wind Sensor



Note: Please refer to the Met One 034B wind sensor user manual for detailed installation, calibration and maintenance information

The Model 034B Wind Sensor combines wind speed and direction measurements into a single sensing unit.

The 034B Wind Sensor installs in minutes and will provide accurate, long term, continuous monitoring in hostile environments.

Features

- Wind speed and direction in a single sensor
- Long field life
- Durable aluminum and stainless-steel construction
- Low starting threshold
- Stainless steel bearings
- Ultra-low power operation
- Easy maintenance

Wind sensor components

The wind sensor consists of four parts:

1. Sensor body
2. Vane
3. Alignment adapter
4. 50 feet of Cable with quick disconnect

Heated Wind Sensor



Note: Please refer to the Met One 014A and 024A sensor user manuals for detailed installation, calibration and maintenance information.

Model 024A Wind Direction Sensor and Model 014A Wind Speed Sensor are provided with heaters to prevent the build-up of ice and snow.

Wind Sensor components

The wind sensor consists of four parts:

1. Wind Speed Sensor
2. Wind Direction Vane
3. Cross arm
4. (2) Two 10 meter sensor cables with quick disconnect connectors
5. Heater (Optional)

Technical Specifications:

014A Wind Speed Sensor

Range: 0 - 135 mph (60 m/s)

Starting Threshold: 1.0 mph (0.45 m/s)

Accuracy: ± 0.25 mph (0.11 m/s) or 1.5% Full Scale

Operating Range: -50°C to $+70^{\circ}\text{C}$ (-58°F to $+158^{\circ}\text{F}$)

Weight: 11 oz (.31 kg)

Finish: Clear anodized aluminum

Ingress Protection: IP54

024A Wind Direction Sensor

Range: 0° - 360°

Accuracy: $\pm 5^{\circ}$


Operating Range: -50°C to $+70^{\circ}\text{C}$ (-58°F to $+158^{\circ}\text{F}$)

Weight: 1 lb 2 oz (.45 kg)


Finish: Clear anodized aluminum

Ingress Protection: IP54


Heated Wind Sensor Cross arm




Heated Wind Sensor Heater Assembly



Dimensions



014A Wind Speed Sensor



024A Wind Direction Sensor

R.M. Young Wind Monitor



Note: Please refer to the R.M. Young 05103-11 Wind Monitor user manual for detailed installation, calibration and maintenance information.

The Wind Monitor requires a special modification to the Control Module and the Wind Monitor electronics circuit.

Technical Specifications:

Wind Speed

Range: 0 - 224 mph (100 m/s)

Accuracy: ± 0.6 mph (0.3 m/s) or 1% of reading

Wind Direction

Range: 0 – 360°

Accuracy: $\pm 3^\circ$

Temperature Sensor



The Capricorn FLX includes one temperature sensor with 50 feet of cable and a quick disconnect connector pair. Up to four temperature sensors can be connected to the control module.

Relative Humidity Sensor



This optional capacitive relative humidity sensor is compact and easy to use. It can be easily installed in a self-aspirating radiation shield for protection from the sun and rain. This sensor offers long-term stability with minimal drift. Because the sensor is a capacitive device, it will not be affected by surface contamination in unclean environments. The sensor element is socketed, and laser trimmed to allow for replacement in the field without additional calibration. The relative humidity sensor comes with a standard 50-foot cable and a quick disconnect connector pair.


Tipping Bucket Rain Gauge (Optional)




The optional tipping bucket rain gauge is composed of a complex spun collector funnel with a knife-edge that diverts the water to a tipping bucket mechanism. Each tip causes a momentary closure of a switch to incrementally measure rainfall accumulation. The rainfall sensor is completely automatic - spent water drains out of the bottom of the housing; hence, the instrument requires no servicing. The rain gauge comes with a standard 50-foot cable and a quick disconnect connector pair.

Rain Gauge Installation

The rain gauge can be installed on a flat surface using three screws, not provided. It can also be installed on a mast using the provided hose clamps.




Mount the rain gauge
on a flat surface
using three screws
(not provided)



Surface Mounted

Mast Mounted



Hose Clamps
Supplied

Tipping Bucket Rain Gauge Options

Heated Option

The Tipping Bucket can also be configured with a heater to melt ice and snow build-up on the top of the sensor.

The sensor has two heaters, one is attached to the underside of the inner collector funnel and one is attached to the inside lower portion of the sensor housing. These two heaters are connected in series with a thermostat that is positioned near the tipping assembly. When the outside temperature drops to approximately 45°F, the thermostat will start to cycle.

Power requirement:

Voltage: 120VAC

Total amperage: 1.65 Amps max

Collector Heater: 65 Watts

Housing Heater: 116 Watts

4 – 20mA Interface Option

The optional tipping bucket rain gauge can also be configured to provide 4 – 20mA interface to a PLC system.

The 4-20mA readings reset once per minute.

4-20mA Scaling:

4mA = 0 inches of rain

20mA = 0.32 inches of rain

Signal Wiring:

Red: 10 – 33VDC

Black: Common

White: Signal

Solar Radiation Sensor - Pyranometer (Optional)



The Pyranometer is designed for routine measurement of global hemispherical solar radiation under all weather conditions. The sensor has a rugged uni-body design, which houses a high-performance silicon photodiode detector mounted beneath a conical shaped (self-cleaning) diffuser. Due to the unique diffuser design, the sensitivity of this sensor is proportional to the cosine of incidence of the incoming solar irradiance, allowing for accurate and consistent measurement. The solar radiation sensor comes with a standard 50-foot cable, a quick disconnect connector pair and a leveling plate for obtaining more accurate measurements.

WeatherMaster™ Software (Optional)



WeatherMaster is professional grade weather monitoring software designed for specialized markets that require robust weather calculations, interoperability with computer models, and data interfaces to other industrial systems. WeatherMaster utilizes Microsoft Access database for easy data access and manipulation.

Please refer to the WeatherMaster user manual for installation and operation procedures.

Weather MicroServer™ (Optional)

The Capricorn FLX Control Module connects to the MicroServer via COM1.

The Weather MicroServer uses a small computer board that runs an embedded Linux operating system.

The MicroServer has 128MB flash memory for operation and 8 GB SD card for data logging.

The MicroServer has two RS-232 COM ports and an Ethernet port.

The Capricorn FLX can also be configured for RS-485 communication and connects to COM2.



The MicroServer offers the following:

- XML Weather Data
- FTP weather data in XML or CSV format
- Modbus/TCP, Modbus RTU (Serial RS-485) interfaces
- SNMP, BACnet, DNP3 Ethernet & Serial interfaces
- Weather Underground & CWS Weather Server interface
- CWOP interface
- One year of data logging at 1-minute interval
- Interface to optional visibility, solar radiation sensors, and temperature sensors

Please refer to the Weather MicroServer user manual for more information.

Weather Display Console (Optional)



Displays weather information • Designed to be viewed clearly from a distance • Industrial grade WVGA touchscreen.

Seven-inch, TFT color LCD panel with 800 x 480 pixel resolution.

Performs computations for wind chill, heat index and other calculated parameters • 200MHz ARM9 CPU

Serial or Ethernet connection: Connects directly to weather station with serial port or connects to a Weather MicroServer™ over a network utilizing an existing Ethernet infrastructure. The MicroServer configuration also allows for data from one weather station to be monitored from multiple display consoles at various locations.

Screens can be factory-customized to meet specialized market and industry requirements.

The Weather Display is also available in a 19" rack-mount chassis and a panel-mount configuration.

Please refer to the Weather Display Console user manual for more information.

SECTION 3: INSTALLATION

Wiring and Color Code

Terminal #	Wire Color	Description
Solar Radiation 1		
1	RED	+3.3V
2	BARE	Ground
3	BLACK	Solar Signal
Relative Humidity		
4	RED	+12V
5	BARE	Ground
6	BLACK	Humidity Signal
Wind Direction		
7	WHITE	Reference Voltage
8	GREEN	Ground
9	BROWN	Wind Direction Signal
Wind Speed (same cable as wind direction)		
10	N/C	No Connection
11	BLACK	Ground
12	RED	Wind Speed Signal
*22	BLUE	Reference Voltage
Wind Direction (Heated)		
7	RED	Reference Voltage
8	BLACK	Ground
9	CLEAR	Wind Direction Signal
Wind Speed (Heated)		
10	N/C	No Connection
11	BLACK	Ground
12	RED	Wind Speed Signal
Rainfall		
13	N/C	No Connection
14	RED	Ground
15	BLACK	Rain Signal
Temperature 1		
16	RED	+3.3V
17	BARE	Ground
18	BLACK	Temperature 1 Signal
Solar Radiation 2		
19	RED	+3.3V
20	BARE	Ground
21	BLACK	Solar Signal

Analog Sensor 1

22	RED	+3.3V
23	BARE	Ground
24	BLACK	Signal

Analog Sensor 2

25	RED	+3.3V
26	BARE	Ground
27	BLACK	Signal

Temperature 2

28	RED	+3.3V
29	BARE	Ground
30	BLACK	Temperature 2 Signal

Temperature 3

31	RED	+3.3V
32	BARE	Ground
33	BLACK	Temperature 3 Signal

Temperature 4

34	RED	+3.3V
35	BARE	Ground
36	BLACK	Temperature 4 Signal

*R.M. Young Wind Monitor only

Installation Overview

Unpacking the Unit

Installing the Control Module

Installing the Mast

Routing the Sensor Cables

Installing the Barometric Pressure Sensor

Installing the Temperature & Relative Humidity Sensors

Installing the Wind Sensor

Installing the Optional Rain Gauge Sensor

Installing the Optional Solar Radiation Sensor

Unpacking the Unit

Unpack the Capricorn FLX weather station and verify that all parts are included.

Inspect all system components for obvious shipping damage (Refer to page 4 in case of damage).

Save the shipping carton and packing material in case the unit needs to be returned to the factory. Note: If items are missing or if there is damage, see page 4. If the system does not operate or calibrate properly, see Section 10: Maintenance and Section 11: Troubleshooting, for further instructions.

Unpack the Capricorn FLX weather station and verify that all parts are included.

1. Standard system includes:

- Control Module
- (12) 3-position terminal blocks
- Power Supply
- Temperature Sensor with 50ft cable
- Relative Humidity Sensor with 50ft cable
- Self-Aspirating Radiation Shield for Temp & RH Sensors
- Wind Speed and Direction Sensor with 50ft cable
- 6-foot RS-232 cable + additional cable length if ordered
- User Manual

- Optional Tipping Bucket Rain Gauge
 - Optional Solar Radiation Sensor
2. WeatherMaster software and user manual **(Optional)**
3. Weather MicroServer **(Optional)**
- MicroServer
 - Power supply
 - 7-foot Ethernet cable
 - User manual
4. Weather Display Console **(Optional)**
- Display Console
 - Power supply
 - 6-foot RS-232 cable + additional cable length if ordered
 - User manual

Installing the Control Module

Place the Capricorn FLX Control Module in a clean, dry location.

After powering the control module connect the Chassis Ground terminal to a good earth ground.

Note: It is strongly recommended that you protect your unit from power line spikes (caused by lightning or electrical discharge) by installing a high-quality spike-surge suppression device between the Control Module and the power source.

Installing the Mast

There are three methods for mounting the mast to a roof or building structure: Sloped roof mounting, flat roof mounting or wall mounting. See Section 4: Optional Sensor Mounting Hardware for more information.

Routing the Sensor Cables

Use plastic tie wraps to secure the sensor cables to the mast, particularly at the mast base. Tighten the tie wraps securely and clip off any excess length with a wire cutter tool.


Once the sensors have been placed, route the cable back to the Control Module or weatherproof enclosure.

Any mast or tower should always be properly earth grounded to minimize electrical storm damage. The use of a properly grounded metal mast or tower, however, does not insure protection from electrostatic discharge. These items could become electrically charged resulting in damage to the sensors and/or console. This could damage the system in the event of an electrical storm.

Barometric Pressure Sensor Settings

The barometric pressure sensor is located inside the Control Module; no user installation is required. Please refer to Section 9: Calibration, for the procedure to set the altitude.

Installing the Temperature and Humidity Sensors



The temperature and relative humidity sensors should be mounted in a sheltered area, preferably on the north side of a building.

Insert both humidity and temperature sensors in the radiation shield to the midway point and secure both cables to the plastic fastener on the mounting bracket using the provided tie wrap.

Both sensors are supplied with a standard 50-foot cable. The cable provided is a 22-gauge, 2 conductor shielded cable with a ground drain lead.

Once the sensors have been placed, route the cables back to the Control Module.

Using a small straight screwdriver, attach the wires from the end of the temperature cable to the Temperature 1 terminal block on the Control Module as follows:

- Red Wire - Terminal #16
- Bare Wire - Terminal #17
- Black Wire - Terminal #18

Using a small straight screwdriver, attach the humidity cable to the RH terminal block on the Control Module as follows:

- Red Wire - Terminal #4
- Bare Wire - Terminal #5
- Black Wire - Terminal #6

Installing Additional Temperature Sensors

The standard model is supplied with only one temperature sensor. However, additional sensors can be added at any time (Part No. 82100). The Capricorn FLX can accept up to four temperature sensors.


By default, the Temperature channel outputs a reading of 255°F with no sensor connected to the terminal.

Installing the Standard Wind Sensor


Assembling the Standard Wind Sensor

Note: Please refer to the Met One 034B wind sensor user manual for detailed installation, calibration and maintenance information.


Please read these instructions carefully to insure a safe and reliable installation.



Mounting Adapter



All dimensions are in inches



Install Vane

1. Fully insert vane arm into hub
2. Align vane with center axis of sensor
3. Using the provided 7/64" Allen wrench, tighten set screw thru top of hub

Sensor Installation

1. Install the mounting adapter onto the sensor base and tighten the socket head cap screw using the provided 7/32" Allen wrench
2. Place the sensor with adapter on top of the mast
3. Rotate entire sensor until vane tail points to "True North"
4. Tighten both set screws, clamping adapter to mast, using 7/32 Allen wrench
5. Remove shoulder screw from hub and save. Connect sensor cable

Mounting Method

Choose the appropriate mounting method for the installation and obtain the necessary mounting hardware. Refer to Section 4 for information on available optional sensor mounting hardware and accessories.

Do not mount sensors close to power lines.

Once the Wind Sensor has been mounted, route the cable back to the Control Module

Using a small straight screwdriver, attach the wires from the end of the Wind Sensor cable to the Wind Speed & Direction terminal blocks on the Control Module as follows:

Wind Direction:

White Wire	- Terminal #7
Green Wire	- Terminal #8
Brown Wire	- Terminal #9

Wind Speed (same cable as wind direction):

No Connection	- Terminal #10
Black Wire	- Terminal #11
Red Wire	- Terminal #12

Connect the bare wire to the chassis ground terminal on the front panel of the Control Module enclosure.

Installing the Heated Wind Sensor

Choose the appropriate mounting method for the installation and obtain the necessary mounting hardware. Refer to Section 4 for information on available optional sensor mounting hardware and accessories.

Do not mount sensors close to power lines.

Once the Wind Sensors have been mounted, route the cables back to the Control Module.

Using a small straight screwdriver, attach the wires from the end of the Wind Sensor cables to the Wind Speed & Direction terminal blocks on the Control Module as follows:

Wind Direction


RED Wire	- Terminal #7	Reference Voltage
BLACK Wire	- Terminal #8	Ground
CLEAR Wire	- Terminal #9	Wind Direction Signal

Wind Speed (same cable as wind direction):

No Connection	- Terminal #10	No Connection
Black Wire	- Terminal #11	Ground
Red Wire	- Terminal #12	Wind Speed Signal

Connect ground lugs to grounding post on Capricorn FLX Control Module.

Installing the R.M. Young Wind Monitor



To mount the wind monitor, follow the directions below:

1. Insert the Mounting Adapter into the wind monitor
2. Align the North Orientation Ring so that the indexing pin is inserted into the notch at the instrument base
3. Tighten the hose clamp around the Mounting Adapter
4. Align the two arrows
5. Locate True North (e.g. using smartphone compass app)
6. Rotate the entire assembly so that the front of the wind monitor is pointing to True North
7. Tighten the set screws using the provided hex key

Once the Wind Monitor has been mounted, route the cables back to the Control Module.

Using a small straight screw driver, attach the wires from the end of the Wind Monitor cables to the Wind Speed & Direction terminal blocks on the Control Module as follows:

Wind Direction:

White Wire	- Terminal #7	Reference Voltage
Green Wire	- Terminal #8	Ground
Brown Wire	- Terminal #9	Wind Direction Signal

Wind Speed (same cable as wind direction):

No Connection	- Terminal #10	
Black Wire	- Terminal #11	Ground
Red Wire	- Terminal #12	Wind Speed Signal
Blue Wire	- Terminal #22	(A1) Reference Voltage

Installing the Rain Gauge Sensor

Safety Note: The top rim of the rain gauge sensor is **EXTREMELY sharp**. Handle the rim with great care.

The rain gauge is supplied with a standard 50-foot, 22-gauge, 2 conductor shielded cable with a ground drain lead.

To obtain an accurate reading, mount the Rain Gauge Sensor in a clear and open area, either surface or mast mounted in a LEVEL position and in a location free from vibration.

When mounting with other sensors on a mast, position the Rain Gauge as the lowest sensor in the vertical stack to avoid drainage on other sensors. Rotate any sensors mounted above the Rain Gauge away to provide an unobstructed rain path

Once the Rain Gauge Sensor is securely mounted, grasp the top gold funnel portion of the Rain Gauge Sensor firmly and lift up. **Do Not** place any part of your hand on the rim of the Rain Gauge due to the sharp knife edge. Verify that the black tipping bucket is not in a center position and that one end of the bucket is down against the stop. Replace the top gold funnel portion of the Rain Gauge Sensor.

Once the Rain Gauge Sensor has been placed, route the cable back to the Control Module

Using a small straight screwdriver, attach the wires from the end of the rain cable to the Rain terminal block on the Control Module as follows:

No Connection	- Terminal #13
Red Wire	- Terminal #14
Black Wire	- Terminal #15

Installing the Solar Radiation Sensor

The solar radiation sensor should be installed in an area that receives full sunlight throughout the year away from any object that can create a shadow over the sensor.

The sensor should be mounted on a leveled surface. For accurate readings use the provided leveling plate.

Once the solar radiation sensor is mounted, route the cable back to the Control Module.

Using a small straight screwdriver, attach the wires from the end of the solar cable to the Solar 1 terminal block on the Control Module as follows:

Red Wire	- Terminal #1
Bare Wire	- Terminal #2
Black Wire	- Terminal #3


SECTION 4: OPTIONAL SENSOR MOUNTING HARDWARE

Sensor Mast

10-foot steel mast available for use with Roof Mount Hardware Kit (Part No. 88002) or Wall Mount Kit (Part No. 88003).

Roof Mounting

The Roof Mounting Kit (Part No. 88002) is suitable for both a slanted and flat roof installation. The figure and table below illustrates and describes the individual parts.




Description	Ref.	Qty.	Part No.
Steel mast, 10 ft.	1	1	88005
Universal Mast Anchor	2	1	88010

Lag Screw, Roof Mast Mount 1/4" x 2 1/4" (for comp. roofs)	3	4	88030
Guy Wire Clamp, 1/8"	4	1	88070
Steel Guy Wire, Galvanized	6	50ft.	88080
Eye Bolt Wood Screws, 1/4" x 3"	7	4	88090
Turnbuckles, 6" open x 4" closed (not shown)	3		88100

Wall Mounting

The figure and table below illustrates and describes the individual parts in the Wall Mounting Kit (Part No. 88003). Individual parts are also available.



Telescoping Tripod and Tiedown Kit




The tripod is designed to provide up to 10 feet of stable, secure support for your meteorological sensors.

Constructed from welded anodized aluminum for appearance and longevity, the 15-pound tripod can easily support up to 60 pounds of equipment. An optional tie-down kit allows for additional security in high-wind areas.

To install, insert the legs into the main body, secure with stainless steel retainer pins. Extend the mast to the desired height, insert another retainer pin and install the guy wires to complete the set-up.

Tripod Parts List:



Description	Ref.	Qty.
Body/Mast Assembly	1	1
Legs	2	3
Retainer Pins	3	4
Guy Wire Ring with 3 Wires and Turnbuckles	4	1
Anchor Screw with Chain	5	1
Clamp with Strap	6	1

Specifications

Capacity: Supports up to 60 lbs.


Shipping Weight: 17 lbs.

Shipping Box Dimensions: 71" x 9" x 9"

Tripod and Tiedown Kit Catalog Number: 88019

SECTION 5: OPERATION

Connecting the Control Module to a Computer



Connect the provided RS-232 cable and DB-9 connector (female) to the serial port on the Control Module, securing it with the attached screws.

Connect the other end of the RS-232 cable and DB-9 connector to an available serial port on the computer.

A serial to USB converter may be required if the computer or laptop does not have a serial port installed.

Operating software

Once an RS-232 connection is established between the computer and the weather station, WeatherMaster (optional) can be used to view the data.

A "Terminal" program such as PuTTY or HyperTerminal can also be used to view the data.

Communication Settings

The protocol for both serial ports is the following:

Bits per Second (baud rate): 9600

Data bits: 8

Parity: None

Stop bits: 1

Flow control: None

RS-232 Output

The Capricorn FLX outputs the weather data over an RS-232 serial connection.

Once the Control Module is properly connected to a terminal program a record will be displayed once per second.

The wind speed and direction measurements update once every second.

All other measurements including temperature, relative humidity, barometric pressure, rainfall, solar, and analog readings update once every 10 seconds.

The following are examples of the weather data output:

```
0Cap,0003,Dm=283D,Sm=0.0S,Ua=45P,Pa=29.867I,TA=70.7F,TB=255.0F,TC=255.0F,TD=255.0F,Rc=0.00I,AA=0.244V,AB=0.592V,AC=0.591V,AD=0.634V,Dof
```

"0003" indicates new wind speed and direction measurements

```
0Cap,FFFF,Dm=282D,Sm=0.0S,Ua=46P,Pa=29.867I,TA=70.7F,TB=255.0F,TC=255.0F,TD=255.0F,Rc=0.00I,AA=0.328V,AB=0.592V,AC=0.591V,AD=0.622V,B z
```

"FFFF" indicates new measurements for all parameters.

Fields Definition:

Dm = Wind Direction (°)

Sm = Wind Speed (mph)

Ua = Relative Humidity (%RH)

Pa = Barometric Pressure (InHg)

TA = Temperature 1 (°F)

TB = Temperature 2 (°F)

TC = Temperature 3 (°F)

TD = Temperature 4 (°F)

Rc = Rainfall (inches)


AA = Solar 1 (Volts)

AB = Solar 2 (Volts)

AC = Analog 1 (Volts)

AD = Analog 2 (Volts)


Connecting the Control Module to the Weather MicroServer



Connect the provided RS-232 cable and DB-9 connector (female) to the serial port on the Control Module, securing it with the attached screws.

Connect the other end of the cable and DB-9 connector (male) to COM 1 on the MicroServer, securing it with the attached screws.

Connecting the Control Module to the Weather Display Console




Connect the provided RS-232 cable and DB-9 connector (female) to the serial port on the Control Module, securing it with the attached screws.


Connect the other end of the cable to the serial port (bottom port) on the Weather Display Console.

SECTION 6: OPTIONAL CONFIGURATIONS

RS-485 Configuration



For cable lengths longer than 200ft, the Capricorn FLX is configured to output the weather data over an RS-485 communication line. An internal jumper is set to configure the Control Module for RS-485 communication.




The RS-485 system includes the Control Module, sensors, sensor cables, weatherproof enclosure, power supply and an RS-485 to RS-232 Converter.

The RS-485 signal is converted to RS-232 in order to connect to a monitoring device.

An RS-232 Interface Module is available as an option to connect the weather station to multiple devices.

Refer to Section 3: Installation for instructions to connect the sensors to the Control Module.

Wireless System



The wireless Capricorn FLX Weather Station communicates via a wireless link with monitoring devices such as the MicroServer, Display Console or a computer running WeatherMaster software.

This configuration includes the Control Module, sensors, sensor cables, one pair of wireless transceivers, power supplies and a weatherproof enclosure.

The server transceiver is located near the weather station and is housed in the weatherproof enclosure. A client transceiver is connected to a monitoring device. An optional RS-232 Interface Module is available to connect the wireless transceiver to multiple devices.

The 2.4GHz transceivers are capable of communicating at a distance of 1 mile with a clear line-of-sight.

The 900MHz transceivers are capable of communicating at a distance of 20 miles with a clear line-of-sight.

Refer to Section 3: Installation for instructions to connect the sensors to the Control Module.

During normal operation the wireless transceiver pair will function as follows:

Transmitter (2.4GHz)

Red Power LED: Blinks Twice/Second

Green TX (Transmit) LED: Blinks Once/Second

Yellow RX (Receive) LED: OFF

Signal Strength: OFF

Receiver (2.4GHz)

Red Power LED: Blinks Twice/Second

Green TX (Transmit) LED: OFF

Yellow RX (Receive) LED: Blinks Once/Second

Signal Strength: All three LEDs should be lit depending on line-of-sight.

Transmitter (900MHz)

Red TX/Power LED: ON Solid

Green Data In LED: Blinks Once/Second

Yellow Data Out LED: OFF

Signal Strength: OFF

Receiver (900MHz)


Red TX/Power LED: ON Solid

Green Data In LED: OFF

Yellow Data Out LED: Blinks Once/Second

Signal Strength: All three LEDs should be lit depending on line-of-sight.

Solar Powered System



The Capricorn FLX Control Module is well suited for solar power due to its low power consumption.


This configuration includes the Control Module, sensors, sensor cables, wireless transceiver, one 12 Volt battery and a 10-Watt solar panel with regulator.

The system includes two weatherproof enclosures; one to house the Control Module and wireless transceiver, the other the 12 Volt battery.

This system connects to optional monitoring devices via a wireless link. The monitoring devices are powered by AC power (120/240VAC).

Refer to Section 3: Installation for instructions to connect the sensors to the Control Module.

Capricorn FLX 420 System



The Capricorn FLX 420 System provides 4-20mA output for industrial interface to PLC, DCS, and SCADA systems.

The station provides eight 4-20mA output channels including wind direction, wind speed, temperature, relative humidity, barometric pressure, rainfall, solar radiation and a reserved channel for an optional sensor.

This configuration includes the Control Module, sensors, sensor cables, power supply, surge arrestor and two 4-20mA converter(s) housed in a weatherproof enclosure.

Additional monitoring options, including the Weather Display Console, Weather MicroServer and WeatherMaster software can be connected to the system via an RS-232 cable.


Refer to Section 3: Installation for instructions to connect the sensors to the Control Module.

Note: The 4-20mA converters source power to the load.

420 Weatherproof Enclosure



Serial to 4-20 m Amp Converter
www.columbiaweather.com



Ch1: Wind Direction Range: 0 to 360 degrees	Ch5: Barometric Pressure Range: 14.8 to 32.5 in-Hg
Ch2: Wind Speed Range: 0 to 160 mph	Ch6: Rainfall Range: 0 to 10 inches
Ch3: Temperature Range: -67 to +257 °F	Ch7: Solar Radiation Range: 0 to 1250 W/m-2
Ch4: Relative Humidity Range: 0 to 100%	Ch8: Optional Sensor Range: See Documentation

The Capricorn FLX 420 outputs the following parameters in 4-20 mA current signals:

Channel 1: Wind Direction

Description: Instantaneous wind direction.

Range: 0 to 360 degrees

Channel 2: Wind Speed

Description: Instantaneous wind speed.

Range: 0 to 160 mph

Channel 3: Temperature

Description: Instantaneous temperature.

Range: -67° to 257°F

Channel 4: Relative Humidity

Description: Instantaneous relative humidity.

Range: 0 to 100%

Channel 5: Barometric Pressure

Description: Instantaneous barometric pressure.

Range: 14.8 to 32.5 inches Hg

Channel 6: Rainfall

Description: 0.01 inches rain accumulation.

Range: 0 to 10.00 inches

The rain accumulates until 10.00 inches is reached at which point the rain will reset to 0.01 inches.

The accumulation measurement will reset to zero when power to the Control Module is lost.

Channel 7: Solar Radiation Sensor

Description: Instantaneous solar radiation.

Range: 0 to 1250 W/m²

Channel 8: Optional Sensor

Range: See Order Documentation

SECTION 7: CALIBRATION

Calibrating the Barometric Pressure Sensor

The barometric pressure sensor is calibrated at the factory to a highly accurate digital pressure gauge ($\pm 0.02\%$ of full range). No field calibration is required.

Altitude Setting

After calibration at the factory, the altitude is set to zero. To get an accurate barometric pressure reading, the local altitude needs to be set in the weather station. This can be done in any of the available monitoring options including Weather Master Software, the Weather MicroServer and the Weather Display Console.

Note: The barometric pressure sensor is sensitive to changes in elevation of as little as 10 ft. (3 m).

Calibrating the Standard Wind Sensor

General Maintenance schedule:

6-12 month intervals:

- A. Inspect the sensor for proper operation per Section 3.0 of the user manual
- B. Replacement of wind speed sensor bearing in extremely adverse environments

12-24 month intervals:

- A. Replacement of wind speed sensor bearings

24-36 month intervals:

- A. Recommended complete factory overhaul of sensor

Note: Please refer to the Met One 034B wind sensor user manual for detailed installation, calibration and maintenance information

Calibrating the R.M. Young Wind Monitor

Note: Please refer to the R.M. Young 05103-11 Wind Monitor user manual for detailed installation, calibration and maintenance information

Calibrating the Humidity Sensor

The humidity sensor is calibrated at the factory. No field calibration is required.

The humidity sensor has a $\pm 2\%$ stability over 2 years. Therefore, we recommend replacing the sensing element every 2 to 4 years.

Calibrating the Rain Gauge Sensor

The rain gauge is calibrated at the factory and does not require any initial field calibration.

The tipping bucket mechanism is a simple and highly reliable device. The transmitter must be located in a clear area, away from trees, buildings, etc. It must also be mounted level. Accurate readings will not be obtained unless the transmitter is mounted in a level position. The mechanism must be clean. Any accumulation of foreign material, dust, etc. will alter the calibration of this unit.

Absolutely accurate calibration can be obtained only with laboratory equipment, but an approximate field check can be easily made. For field calibration, a calibration kit is available from the factory.

Calibrating the Solar Radiation Sensor

The solar radiation sensor is calibrated at the factory. No field calibration is required.

SECTION 8: MAINTENANCE

In normal use, the Capricorn FLX should require very little maintenance. In the event of any problems, follow the procedures contained in Section 11: Troubleshooting, to determine whether the unit is defective. If the unit needs to be returned to the factory for repair, refer to the Return for Repair Procedure in Section 12: User Support Information.

Console Maintenance

The Control Module contains sensitive electronic components and should not be serviced by the user. If the power LED is not on; check for proper installation of the wall mount power supply.

Barometric Pressure Sensor Maintenance

The barometric pressure sensor is located inside the enclosure and should not be serviced by the user.

Temperature Sensor Maintenance

Check the temperature sensor cables during installation and periodically thereafter to make sure they contain no cuts, kinks or other abnormalities.

Standard Wind Sensor Maintenance

Note: Please refer to the Met One 034B wind sensor user manual for detailed installation, calibration and maintenance information

R.M. Young Wind Monitor Maintenance

Note: Please refer to the R.M. Young 05103-11 Wind Monitor user manual for detailed installation, calibration and maintenance information

Relative Humidity Sensor Maintenance

The Relative Humidity sensor does not require any field maintenance.

Rain Gauge Maintenance

Periodically clean the Rain Gauge of any debris that might be clogging the funnel or accumulating in the tipping bucket.

Solar Radiation Sensor Maintenance

Periodically clean the solar radiation sensor lens of any dirt or debris accumulation.

SECTION 9: TROUBLESHOOTING

Wind Sensor (Standard)

The following tests are recommended to help locate the source of faulty wind readings.

Wind Speed Test

1. Disconnect the power supply from the Control Module.
2. Using a small straight blade screwdriver remove the wind sensor wires from their terminals on the Control Module.
3. Reconnect the power supply to the Control Module.
4. Using a 22-gauge jumper wire, connect to terminal #11 and tap the other end on terminal #12. A wind speed reading greater than zero should be displayed.
5. If the wind speed value does not increase from zero, the wind speed channel in the Control Module is defective and should be returned to the factory for repair.
6. If the wind speed value does increase from zero, the wind sensor or the cable is defective. Check the cable for obvious damage. Make sure the cable connector is plugged in the wind sensor correctly and verify the cable connection to the Control Module.
7. If there are no problems with the cable, disconnect the wind sensor and return it to the factory for repair.

Note: Please follow the procedure in Section 12: User Support Information for returning any defective items to the factory.

Wind Direction Test

1. Apply power to the Control Module.
2. Set a multimeter to volts DC.
3. Measure the voltage between terminal #7 and #8. Place the black probe on terminal #8 and the red probe on terminal #7. The voltage should be approximately 3.3 volts DC. If the voltage is different, the wind direction channel is defective, and the Control Module should be returned to the factory for repair.

4. To continue troubleshooting; place the black probe of the multimeter on terminal #8 and the red probe on terminal #9.
5. As the wind vane rotates, the voltage reading will vary from 0 to 3.3 volts DC. If the vane is pointing south, the voltage reading should be 1.65 volts.
6. If the voltage reading is not changing when the vane is rotating or if the value is out of the normal range (0 to 3.3 volts DC) the wind sensor is defective and should be returned to the factory for repair.

Note: Please follow the procedure in Section 12: User Support Information for returning any defective items to the factory.

Temperature Sensor Troubleshooting

If the Temperature sensor is reading 255°F, the Temperature sensor may be disconnected from the Control Module, may not be initialized, or may be defective.

Check the cable from the sensor to the Control Module for any cuts or kinks. Check the cable connection to the Control Module.

The initialization procedure should be performed when replacing or adding a sensor or when a sensor has lost its initialization to the Control Module and is reading 255°F.

To initialize a temperature sensor to the Control Module, perform the following procedure:

1. Disconnect power from the Control Module
2. Connect the Temperature Sensor to the appropriate Temperature Channel on the Control Module
3. Reapply power to the Control Module
4. Verify that the Temperature reading is correct

SECTION 10: USER SUPPORT INFORMATION

This section consists of the following items:

1. **One-Year Limited Warranty:** Please read this document carefully.
2. **Return for Repair Procedure:** This procedure is for your convenience in the event you must return your Capricorn FLX for repair or replacement. Follow the packing instructions carefully to protect your instrument in transit.

Limited Warranty

Columbia Weather Systems, Inc. (CWS) warrants the Capricorn FLX Weather Station to be free from defects in materials and/or workmanship when operated in accordance with the manufacturer's operating instructions, for one (1) year from date of purchase, subject to the provisions contained herein. CWS warranty shall extend to the original purchaser only and shall be limited to factory repair or replacement of defective parts.

EXCLUSIONS

Certain parts are not manufactured by CWS (i.e., certain purchased options, etc.) and are therefore not covered by this warranty. These parts may be covered by warranties issued by their respective manufacturers and although CWS will not warrant these parts, CWS will act as agent for the administration of any such independent warranties during the term of this warranty. This warranty does not cover normal maintenance, damage resulting from improper use or repair, or abuse by the operator. Damage caused by lightning or other electrical discharge is specifically excluded. This warranty extends only to repair or replacement, and shall in no event extend to consequential damages. In the event of operator repair or replacement, this warranty shall cover neither the advisability of the repair undertaken, nor the sufficiency of the repair itself.

THIS DOCUMENT REFLECTS THE ENTIRE AND EXCLUSIVE UNDERSTANDING OF THE PARTIES, AND EXCEPT AS OTHERWISE PROVIDED HEREIN, ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, PARTICULARLY THE WARRANTIES OF MERCHANT ABILITY AND/OR FITNESS FOR A PARTICULAR PURPOSE ARE EXCLUDED.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Return for Repair Procedure

1. In the event of defects or damage to your unit, first call the factory Monday through Friday, 8:30 am to 4:00 pm PST, (503) 629-0887 to determine the advisability of factory repair. The Service Department will issue an RMA number (Return Merchandise Authorization) to help us identify the package when received. Please place that number on the outside of the box.
2. In the event factory service is required, return your Capricorn FLX as follows:
 - A. Packing
 - ◆ Wrap Control Module in plastic bag first.
 - ◆ Pack in original shipping carton or a sturdy oversized carton.
 - ◆ Use plenty of packing material.
 - B. Include:
 - ◆ A brief description of the problem with all known symptoms.
 - ◆ Your phone number.
 - ◆ Your return street shipping address (UPS will not deliver to a P.O. Box).
 - ◆ Write the RMA number on the outside of the box.
 - C. Shipping
 - ◆ Send freight prepaid (UPS recommended).
 - ◆ Insurance is recommended. (The factory can provide the current replacement value of the item being shipped for insurance purposes.)
 - D. Send to:

Columbia Weather Systems, Inc.
5285 NE Elam Young Parkway, Suite C100
Hillsboro, Oregon 97124
 - E. C.O.D. shipments will not be accepted.
3. If your unit is under warranty, after repair or replacement has been completed, it will be returned by a carrier and method chosen by Columbia Weather, Inc. to any destination within the continental U.S.A. If you desire some other specific form of conveyance or if you are located beyond these borders, then you must bear the additional cost of return shipment.

4. If your unit is not under warranty, we will call you with an estimate of the charges. If approved, your repaired unit will be returned after all charges, including parts, labor and return shipping and handling, have been paid. If not approved, your unit will be returned as is via UPS COD for the amount of the UPS COD freight charges.

Firmware Licenses and Copyright Information

This device uses software/firmware components that are covered by the following licenses/copyrights.

Upon request, source code for software licensed under the LGPL is available from Columbia Weather, Inc.

Columbia Weather Systems, Inc.
5285 NE Elam Young Pkwy
Suite C100
Hillsboro, OR 97124
503-629-0887
info@columbiaweather.com

Adafruit Industries

Software License Agreement (BSD License)
Copyright (c) 2012, Adafruit Industries
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the copyright holders nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

OneWire

Copyright (c) 2007, Jim Studt (original old version - many contributors since)

The latest version of this library may be found at:
http://www.pjrc.com/teensy/td_libs_OneWire.html

OneWire has been maintained by Paul Stoffregen (paul@pjrc.com) since January 2010. At the time, it was in need of many bug fixes, but had been abandoned the original author (Jim Studt). None of the known contributors were interested in maintaining OneWire. Paul typically works on OneWire every 6 to 12 months. Patches usually wait that long. If anyone is interested in more actively maintaining OneWire, please contact Paul.

Version 2.2:

Teensy 3.0 compatibility, Paul Stoffregen, paul@pjrc.com
 Arduino Due compatibility, <http://arduino.cc/forum/index.php?topic=141030>
 Fix DS18B20 example negative temperature
 Fix DS18B20 example's low res modes, Ken Butcher
 Improve reset timing, Mark Tillotson
 Add const qualifiers, Bertrik Sikken
 Add initial value input to crc16, Bertrik Sikken
 Add target_search() function, Scott Roberts

Version 2.1:

Arduino 1.0 compatibility, Paul Stoffregen
 Improve temperature example, Paul Stoffregen
 DS250x_PROM example, Guillermo Lovato
 PIC32 (chipKit) compatibility, Jason Dangel, dangel.jason AT gmail.com
 Improvements from Glenn Trewitt:
 - crc16() now works
 - check_crc16() does all of calculation/checking work.
 - Added read_bytes() and write_bytes(), to reduce tedious loops.
 - Added ds2408 example.
 Delete very old, out-of-date readme file (info is here)

Version 2.0: Modifications by Paul Stoffregen, January 2010:

http://www.pjrc.com/teensy/td_libs_OneWire.html
 Search fix from Robin James
<http://www.arduino.cc/cgi-bin/yabb2/YaBB.pl?num=1238032295/27#27>
 Use direct optimized I/O in all cases
 Disable interrupts during timing critical sections
 (this solves many random communication errors)
 Disable interrupts during read-modify-write I/O
 Reduce RAM consumption by eliminating unnecessary
 variables and trimming many to 8 bits
 Optimize both crc8 - table version moved to flash

Modified to work with larger numbers of devices - avoids loop.

Tested in Arduino 11 alpha with 12 sensors.

26 Sept 2008 -- Robin James

<http://www.arduino.cc/cgi-bin/yabb2/YaBB.pl?num=1238032295/27#27>

Updated to work with arduino-0008 and to include skip() as of
 2007/07/06. --RJL20

Modified to calculate the 8-bit CRC directly, avoiding the need for
 the 256-byte lookup table to be loaded in RAM. Tested in arduino-0010
 -- Tom Pollard, Jan 23, 2008

Jim Studt's original library was modified by Josh Larios.

Tom Pollard, pollard@alum.mit.edu, contributed around May 20, 2008

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Much of the code was inspired by Derek Yerger's code, though I don't think much of that remains. In any event that was..

(copyright) 2006 by Derek Yerger - Free to distribute freely.

The CRC code was excerpted and inspired by the Dallas Semiconductor sample code bearing this copyright.

```
//-----
// Copyright (C) 2000 Dallas Semiconductor Corporation, All Rights Reserved.
//
// Permission is hereby granted, free of charge, to any person obtaining a
// copy of this software and associated documentation files (the "Software"),
// to deal in the Software without restriction, including without limitation
// the rights to use, copy, modify, merge, publish, distribute, sublicense,
// and/or sell copies of the Software, and to permit persons to whom the
// Software is furnished to do so, subject to the following conditions:
//
// The above copyright notice and this permission notice shall be included
// in all copies or substantial portions of the Software.
//
// THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND,
// EXPRESS
// OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF
// MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND
// NONINFRINGEMENT.
// IN NO EVENT SHALL DALLAS SEMICONDUCTOR BE LIABLE FOR ANY CLAIM,
// DAMAGES
// OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR
// OTHERWISE,
// ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE
// OR
// OTHER DEALINGS IN THE SOFTWARE.
//
// Except as contained in this notice, the name of Dallas Semiconductor
// shall not be used except as stated in the Dallas Semiconductor
// Branding Policy.
//-----
*/
```


stdio.h

/* Copyright (c) 2002, 2005, 2007 Joerg Wunsch
All rights reserved.

Portions of documentation Copyright (c) 1990, 1991, 1993
The Regents of the University of California.

All rights reserved.

Redistribution and use in source and binary forms, with or without
modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright
notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright
notice, this list of conditions and the following disclaimer in
the documentation and/or other materials provided with the
distribution.
- * Neither the name of the copyright holders nor the names of
contributors may be used to endorse or promote products derived
from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND
CONTRIBUTORS "AS IS"
AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO,
THE
IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR
PURPOSE
ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR
CONTRIBUTORS BE
LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR
CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT
OF
SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR
BUSINESS
INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY,
WHETHER IN
CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR
OTHERWISE)
ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF
THE
POSSIBILITY OF SUCH DAMAGE.

\$Id: stdio.h,v 1.29.2.1 2008/02/23 08:59:27 dmix Exp \$
*/

GNU LESSER GENERAL PUBLIC LICENSE
Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc.
51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA
Everyone is permitted to copy and distribute verbatim copies
of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts
as the successor of the GNU Library Public License, version 2, hence

the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages--typically libraries--of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many

libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a)** The modified work must itself be a software library.
- b)** You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.
- c)** You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.
- d)** If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.

(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

- a)** Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)
- b)** Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.
- c)** Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.
- d)** If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.

- e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

- a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.
- b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

Reference

Glossary

Aspirating Radiation Shield

A device used to shield a sensor such as a temperature probe from direct and indirect radiation and rain while providing access for ventilation.

Barometric Pressure

The pressure exerted by the atmosphere as a consequence of gravitational attraction exerted upon the "column" of air lying directly above the point in question.

Celsius Temperature Scale

A temperature scale with the ice point at 0 degrees and the boiling point of water at 100 degrees.

Density Altitude

Density altitude is a meteorological variable that is important to pilots, especially during the summer. The density altitude is the altitude in a standard atmosphere where the density is the same as the given atmospheric density. During a hot muggy summer day, a pilot begins take off from an airport with an elevation of 2500 feet. Because of the warm temperature and the moisture in the air, the airplane has to work as if it was taking off at an airport at an elevation of 6000 feet resulting in the plane needing more power and a longer roll down the runway to take off.

Dew Point

The temperature to which a given parcel of air must be cooled at constant pressure and constant water-vapor content in order for saturation to occur. When this temperature is below 0°C, it is sometimes called the frost point.

Fahrenheit Temperature Scale

A temperature scale with the ice point at 32 degrees and the boiling point of water at 212 degrees.

Global Radiation

The total of direct solar radiation and diffused sky radiation received by a unit horizontal surface. Global radiation is measured by a Pyranometer.

Heat Index

The heat index or apparent temperature is a measure of discomfort due to the combination of heat and high humidity. It was developed in 1979 and is based on studies of evaporative skin cooling for combinations of temperature and humidity.

Pyranometer

It measures the combined intensity of incoming direct solar radiation and diffused sky radiation. The Pyranometer consists of a radiation-sensing element, which is mounted so that it views the entire sky.

Relative Humidity

Popularly called humidity. The ratio of the actual vapor pressure of the air to the saturation vapor pressure.

Sea Level Pressure

The atmospheric pressure at mean sea level, either directly measured or, most commonly, empirically determined from the observed station pressure.

In regions where the earth's surface pressure is above sea level, it is standard observational practice to reduce the observed surface pressure to the value that would exist at a point at sea level directly below.

Solar Radiation

The total electromagnetic radiation emitted by the sun. 99% of the sun's energy output falls within the wavelength interval from 0.15 microns to 4.0 microns, with peak intensity near 0.47 microns. About one-half of the total energy in the solar beam is contained within the visible spectrum from 0.4 to 0.7 microns, and most of the other half lies near infrared, a small additional portion lying in the ultraviolet.

Wind Chill

That part of the total cooling of a body caused by air motion.

Unit Conversion

Speed

Kilometers per hour = 1.610 x miles per hour

Knots = 0.869 x miles per hour

Meters per second = 0.448 x miles per hour

Feet per second = 1.467 x miles per hour

Temperature

Temperature in °C = 5/9 (temperature in °F - 32)

Temperature in °F = (1.8 x temperature in °C) + 32

Distance

Millimeters = 25.4 x inches

Pressure

Millibars = 33.86 x inches of mercury

Kilopascals = 3.386 x inches of mercury

Pounds per square inch = 0.49 x inches of mercury

Standard atmospheres = 0.0334 x inches of mercury

Solar Radiation

BTU/foot² minutes = 0.00529 x watts/meter²

Joules/centimeter² minutes = 0.006 x watts/meter²

Mega joules/meter² day = 11.574 x watts/meter²

Langleys/minutes = 0.00143 x watts/meter²



Columbia Weather Systems, Inc.
5285 NE Elam Young Parkway, Suite C100
Hillsboro, OR 97124

Telephone
(503) 629-0887

Fax
(503) 629-0898

Web Site
<http://www.columbiaweather.com>

Email
info@columbiaweather.com

Catalog Number: 81646
Version 1.27

Printed in U.S.A.